KEY2-345
Key Ring Remote
for GC3 Panel

Need help? Give us a call.
1-877-826-5443

Enroll

STEP 1
Select `SYSTEM SETTINGS` *> Enter* Master Code *>* Scroll Down *>*
Select `INSTALLER TOOLBOX` *> Enter* 2010.

STEP 2
Select `SYSTEM CONFIGURATION` *> Select* `KEYFOBS` *>* Scroll
down until you see the desired keyfob or next free zone.

STEP 3
Select `EDIT KEYFOB` *> Select* `ENABLED` *> Select* the down arrow.

STEP 4
Select "0866-KEY2-345 4-button Keyfob" *> Select* the down arrow.

STEP 5
Either enter the 7 digit TXID # on the back of the keyfob or
select `LEARN` and remove the back plate then *select* `ACCEPT` *>*
Select the down arrow.

STEP 6
Select "New" *> Select* down arrow.

STEP 7
Select `AUXILIARY` *> Select* the down arrow.

STEP 8
Select `ENABLED` *> Select* the down arrow.

STEP 9
Select `EDIT VOICE DESCRIPTOR` and choose from list at top or
type desired word. If word is available it will show at the top *>*
Select `DONE` .

STEP 10
Select `DISABLED` *> Select* the down arrow.

STEP 11
Select `NEXT KEYFOB` if you have other keyfobs to program or
select `RETURN TO SYSTEM CONFIGURATION` if you are done then
select the left arrow then *select* `SAVE` .

LINK®
INTERACTIVE